
KASARAGOD
KOTTAYAM - ERNAKULAM
THIRUVANANTHAPURAM
COCHIN AIRPORT STATION
ERNAKULAM STATION
SILVER LINE ALIGNMENT
KOTTAYAM STATION
Main Central Rd
Main Eastern Hwy
Eroor Rd
Vechoor Rd
MC Rd
Periyar Nagar
Kolenchery
Puthenkurish
Varapuzha
Kakkanad
Ernakulam
Kochi
Piravom
Thalayolaparambu
Vaikom
Enanalloor
Manjalloor
Thodupuzha
Muvattupuzha
Ramapuram
Pala
Puliyannoor p
Ettumanoor
Kottayam
Google Earth
Image © 2020 Maxar Technologies
© 2020 Google
Image © 2020 CNES / Airbus
Data SIO, NOAA, U.S. Navy, NGA, GEBCO